

Care and Maintenance Tips

By following a few general maintenance tips, you can be assured of having many years of trouble free windows.

- Clean all operating hardware, hinges and tracks at least twice per year and lubricate lightly with a silicone spray or light oil.
- Do not clean glass or other finishes with abrasive materials or cleaners.
- Clean vinyl surfaces with mild soap and water.
- Care should be taken to ensure weather-stripping and hardware is not painted over. This could hamper the operation and seal of the window and cannot be claimed under the warranty as a manufacturing defect.
- Inspect glazing coex annually to ensure proper seal against the glass.
- We recommend removing the internal screens during the winter months to lessen the likelihood of condensation forming on the glass surfaces.